


Dual wheels cushion PU pitching machine User instruction

Parts list Kindly be sure all parts fine before assembling



①Machine 1 ②Cushion 1 ⑤Unit holder 3



③Connection Part ④Screw tools 1set ⑥Balls 3 ⑦ Sand bag 1

Assembly Shown



Hang on the sand bag for balancing weight

Installation



Align the cushion to the bottom of unit's screw hole and sue the tool to screw.

1. Assemble the cushion with unit as A.
2. Assemble the connection part with cushion and lock the safty as B.
3. Insert the rest of holders to connection part as C.

How to adjust strength




Change the different types of pitching such as straight,curve balls.
By adjusting left and right to the same number can get straight.
By adjusting differ strength from each sides can get curve balls.

How to adjust vertical

Adjust to vertical by turning the lever. Lock way back once getting demanding angle.



How to adjust ball of carriage



Pull the tab out in order to adjust the ball of carriage. Insert the tab once done.

How to adjust angle

Adjust angle by turning the wheel handle. Turn the opposite back once getting demanding angle.



Wheel handle

NOTE!

- Please don't use product on raining days.
- Please keep it dry.
- Do not use it on wet surface.
- Adult assembly and supervision required.
- All person(s) not batting should stand behind the pitching machine.
- Do not use the product for any other purpose or with any other object.
- If the product jams, turn machine to "OFF" position.
- Keep product away from high temperature or any fire place.
- Please clean product once training session finished.

MADE IN CHINA